

Injector Adapter 1

This adapter is for vehicles that have an injector circuit check engine light and run in safe mode due to wiring the injectors channels for +/-.

Not used for 6 cylinder vehicles.

• Mitsubishi

CT9A (~) 03.01 ~
CU2W 02.06 ~

• Subaru

GDA/B 00.10 ~
BE/BH5 98.6 ~

Injector Adapter 2

This adapter is used for vehicles that get a very rich condition when wiring the injector channels for +/-.

This adapter is build into the e-manage Ultimate hardware from serial num. 4000 - on.


Injector Adapter 3, Injector adapter 3 (6 Cylinder)

This adapter is for vehicles that have an injector circuit check engine light when wiring the injector channels for +/-.

《 How to Connect 》


1. Connect the Adapter Red wire to a 12V(IGN) power source
2. Connect the Green wires to each Injector Input Channel, in no specific order.

• 4 Cylinder guide



If green wires remain disconnected, please tape the ends to prevent short circuit.

• 6 Cylinder guide



Injector Adapter 1 is for 4 cylinder only.