



Vehicle Name	Chassis	Engine	Year	ECU Location	Diagram to use	Sensor Type
Integra GS-R incl. Type R	DA6	B17A1	92-93	c	WH-1	PR-6
	DC2	B18C1	94-95	a	WH-1	PR-6
		incl. B18C5	96-98	a	WH-2	PR-6
			99-	a	WH-3	PR-6
Prelude	BB1	H22A	92-95	c	WH-1	PR-6
	BB6	H22A	96	c	WH-2	PR-6
			97-	c	WH-2	PR-6
Civic EX, Si	EJ1	D16Z6	92-95	a	WH-1	PR-6
	EJ8	D16Y8	96-98	a	WH-2	PR-6
	EJ8/EM1	D16Y8/B16A2	99-	a	WH-3	PR-6
Del Sol Si Del Sol VTEC	EG1	D16Z6	93	a	WH-1	PR-6
	EG2	B16A2	94-95	a	WH-1	PR-6
			96-97	a	WH-2	PR-6
Accord 2/4 door V-6 only	CG2/CG1	J30A1	98-99	behind radio	WH-2	PR-6
			00-	behind radio	WH-4	PR-6

The only difference in these diagrams is the addition of the VTM wire. The connection of the VTM wire will solve any problems you had before. We apologize for the inconvenience:


WH-1



WH-2



WH-3



WH-4

